

## **Homes that are solar Ready**

When building a new home, consider pre-plumbing for a solar system.

This can be done at little added costs, and used as a marketing tool that the house is

**“Solar ready” !**

- 1. For that one pair of  $\frac{3}{4}$  inch copper pipes** should be installed, running from the mechanical room up to the roof. (please use insulation that is heat resistant like Aeroflex)
- 2. These pipes should end above the finished roof.**
- 3. Besides the piping, a pair of shielded 18-gauge wires** should be installed from the roof to the mechanical room to allow for system controls.